



# GLASSPAK™ PRO

BINOCULAR HARNESS

## INSTRUCTIONS

### STEP 1:

Position the harness so the stitched logo is facing outward with the G-hooks at the top and the side-release buckles at the bottom.



### STEP 2:

Clip the G-hooks into the loops at the top of the backside of the case.



### STEP 3:

Slip the harness over your head so that the harness is on your back and the case is on your chest.



### STEP 4:

Snap the side-release buckles to the buckles at the bottom of the backside of case. Adjust the straps to fit your body snugly so the harness is positioned high and tight on your chest.



### STEP 5:

Roll up and secure any loose straps at the top of the harness.



### STEP 6:

Thread the binocular tether straps through the strap attachments on binocular. Thread the binocular tether straps back through the tether strap buckles to secure.

